

HI-ROLLER CABLE PLACEMENT WHEELS AND ACCESSORIES

U-TECK's Hi-Roller Aerial Cable Placement Wheels are a critical tool used to prevent cable damage while placing Fiber Optic, Coax, and other self-supporting cable

Features:

- Available in two sizes: 24" and 12"
- Lightweight construction
- Dielectrically Safe for Aerial use
- Multi positional swivels for a wide range of pulling angles
- Loading cables is fast and easy
- Easily attached and loaded in seconds
- Lightweight and capable of handling loads not to exceed 1000 lbs.
 - *Fiber Optic Cable recommended load rating is 600LBF*

The Hi-Roller comes with a 3/8" Stainless Steel, multi-swivel slip hook for smooth cable transitions of any angle. Simply attach to suitable existing pole line hardware, or use the "Hi-Roller Pole Strap" (pictured below).



Pole Strap Features:

- Secures the Hi-Roller Aerial Cable Wheels to utility poles or other secure structures.
- Quick Cinching Buckle
- 1.5" Nylon Strapping
- Stainless Steel D-Ring

Hi-Roller Tripod Features:

- Attaches to the 12" Hi-Roller
- Adjustable height from 4 to 7 feet
- Adjustable legs for uneven terrain
- Stakes and leg attachments are included to help stabilize the tripod
- Saves time and personnel when setting up a long pull
- Set up additional tripods for sequential handhole-to-handhole installations

12" Hi-Roller



Accepts cables less than .75" in diameter

24" Hi-Roller



Accepts cables less than 1.5" in Diameter

Ordering Information

Product:	Description:	VPN:
Hi-Roller Cable Placement Wheel 12"	6lbs	59412
Hi-Roller Cable Placement Wheel 24"	18.6 lbs	59424
Hi-Roller Pole Strap	1Lb.	59401
Hi-Roller Tripod	7.5lbs	59410

www.uteck.com | 1-800-542-7011

HI-ROLLER CABLE PLACEMENT WHEEL INSTRUCTIONS



Attach Hi-Roller to existing pole line hardware or pole strap (VPN 59401)



Remove retainer pin



Separate two halves of frame as shown



Allow frame to hang freely (as shown)



Place cable onto wheel



Re-insert retainer pin

HI-ROLLER CABLE PLACEMENT WHEEL INSTRUCTIONS

1. Simply position the tripod over the hand hole.
2. Attach the Hi-Roller Placement Wheel to the eye bolt under the top plate.
3. Attach cable to the Hi-Roller Placement Wheel and pull easily from Handhole to Handhole.
4. Set up additional Tripods as needed.

